

XO

ΣΕΙΡΑ SERIES



TS



TF



TSBK



HS



HSBK



FRS



FRSBK

	80	100	125	125 S	150	150 S	175	200
	12mm	12mm	12mm	16mm	16mm	16mm	16mm	16mm

	80	100	125	125 S	150	150 S	175	200
	20x50	20x50	22x50	27x60	27x60	27x60	27x60	27x60



080	30	105x85	80x60	9	108	38	120		120	1-080-XO.S.-TS	1-080-XO.S.-TF	1-080-XO.S.-TSBK
100	30	105x85	80x60	9	128	38	120		120	1-100-XO.S.-TS	1-100-XO.S.-TF	1-100-XO.S.-TSBK
125	30	105x85	80x60	9	155	45	120		180	1-125-XO.S.-TS	1-125-XO.S.-TF	1-125-XO.S.-TSBK
125S	50	135x110	105x80	11	164	55	146		250	1-125S-XO.S.-TS	1-125S-XO.S.-TF	1-125S-XO.S.-TSBK
150	30	105x85	80x60	9	183	45	120		180	1-150-XO.S.-TS	1-150-XO.S.-TF	1-150-XO.S.-TSBK
150S	40	135x110	105x80	11	194	55	146		300	1-150S-XO.S.-TS	1-150S-XO.S.-TF	1-150S-XO.S.-TSBK
175	40	135x110	105x80	11	217	55	146		300	1-175-XO.S.-TS	1-175-XO.S.-TF	1-175-XO.S.-TSBK
200	40	135x110	105x80	11	239	55	146		300	1-200-XO.S.-TS	1-200-XO.S.-TF	1-200-XO.S.-TSBK

Για κάθε διαφορετική προσαρμογή, αντικαταστήστε το –TS από τον αντίστοιχο κωδικό με πλάκα, με την σχετική περιγραφή (-HS για τρύπα -FRS για πείρο)

Παράδειγμα: 1-100-XO.S-TS με πλάκα
1-100-XO.S-HS με τρύπα
1-100-XO.S-FRS με πείρο

Για φρένο, προσθέστε την κατάληξη –BK στο τέλος του αντίστοιχου κωδικού

Παράδειγμα: 1-100-XO.S-HS με τρύπα
1-100-XO.S-HSBK με τρύπα και φρένο



For each different type of fitting, substitute –TS from the relative code with top plate, with the specific description (-HS for bolt hole -FRS for stem)

Example: 1-100-XO.S-TS with top plate
1-100-XO.S-HS with bolt hole
1-100-XO.S-FRS with stem

For brake, add –BK at the end of the relative code

Example: 1-100-XO.S-HS with bolt hole
1-100-XO.S-HSBK with bolt hole and brake